

INSTRUCTIONS

1. POKE HOLES FOR LEDS
2. TAPE DOWN TRACES IN COPPER TAPE
3. ADD LEDS AND TAPE DOWN ENDS
WITH DOUBLE COPPER TAPE
4. ADD BATTERY AND TEST CIRCUIT
5. ADD SWITCH IF DESIRED
OR CONNECT CIRCUIT
6. ADD CONSTELLATION TO CARD